

USER MANUAL FOR ATX POWER SUPPLY

A. ATX POWER SUPPLY INSTALLATION:

1. Disconnect all the power plugs from the computer.
2. Remove the computer case.
3. Disconnect all AC power connectors
4. On the back of the computer, unscrew the four screws that secure the power supply to the case.
5. With 4 screws fasten the new power supply to the case.
6. Connect the new power supply connector to the appropriate devices inside the computer.
Please note that the power connectors are adapted to be mounted in one way only and if there are problems with the connection, turn the connector and try again.
7. Make sure that all screws are tightened.
8. Set up computer cover and screw.
9. Plug the power cord into an AC outlet.

B. CAUTION:

- Opening ATX power supply housing and breaking guarantee seals located on the power supply results in loss warranty.
- Use in dry and cool places.
- In case of the adapter's damage, deliver it to the closest distributing point and have it repaired or exchanged.
- Do not open the adapter under any circumstances. Opening the adapter's casing is life-threatening due to possible electric shocks.
- Do not let it close.
- Do not expose to mechanical damage, whereas in the case of damage immediately stop the power supply operation.
- Do not throw into fire.
- Do not use this product if it was transferred directly from minus to plus temperature. Occurrence of large temperature difference causes condensation of water drops, which may cause risk of electric shock or damage the device.
- Use this product in accordance with intended use.
- ATX power supply bulk type is not intended for retail sale but it is designed to be used in new computers, which have to be certified as an unity.

C. IN CASE OF PROBLEMS PLEASE CHECK:

- If power cord is properly plug into power supply and if switch is in right position.
- If all power supply output connectors are properly connected to the devices inside the computer.

nTec declares this device complies with the Directives as listed in this document:
EMC 2004/108/WE, LVD 2006/95/WE.

Dispose of according to local regulations.

Producer:
nTec
ul. Chorzowska 44B
44-100 Gliwice
Poland

