

Qoltec[®]



SAFETY WARNINGS FOR USE LASER POINTERS

The following list of safety warnings has been compiled in accordance with the requirements of the General Product Safety Regulation (EU) 2023/988 (GPSR). Its purpose is to protect users from potential hazards arising from the misuse of products. The warnings have been formulated in a simple and understandable way to be accessible to a wide audience, including the elderly and people with reduced mobility.

The laser pointers on offer from manufacturer NTEC sp. z o.o. are CE certified, which proves their compliance with EU safety standards.

Use laser pointers in accordance with their intended use and the manufacturer's recommendations.

BASIC HAZARDS AND PRECAUTIONS

1. Risk of visual damage:

- Never point the laser beam at the eyes of people or animals. Even brief contact can cause permanent damage to the eyes.
- Avoid reflecting the laser beam off mirrored or shiny surfaces to prevent accidentally directing the light into your eyes.

2. Fire risk:

- Do not point the laser at flammable materials or surfaces that may become hot. Strong laser pointers can ignite paper, fabrics or other materials.

3. Risk of misuse:

- Do not use laser pointers as a toy. Keep the device out of the reach of children to avoid accidental use.
- Use the laser pointer only for its intended purpose and as specified in the manufacturer's instructions.

4. Risk of mechanical damage:

- Ensure that the laser pointer is stored and used in such a way as to prevent falls or mechanical damage that may affect the performance of the device.

SPECIFIC RISKS OF USE

5. Hazards in a humid environment:

- Do not use the laser pointer in wet conditions or near water sources unless the device is specifically designed for this purpose.
- If the laser pointer is flooded, immediately disconnect the batteries and contact a service centre.

6. High temperature hazards:

- Avoid using the laser pointer at very low or very high temperatures. Excessive heat can damage the internal electronics.
- Do not store the indicator in areas exposed to direct sunlight.

7. Risk of battery leakage:

- Regularly check the condition of the batteries in the laser pointer. If you notice a leak, remove the batteries immediately and contact the manufacturer.
- Use only batteries recommended by the manufacturer.

MAINTENANCE PRECAUTIONS

8. Cleaning the device:

- Ensure that the laser pointer is switched off and the battery is removed before cleaning.

- Use a soft, dry cloth for cleaning. Avoid using chemicals that may damage the housing of the unit.

9. Maintenance and storage:

- Store the laser pointer in a dry and safe place, away from dust and moisture.
- Regularly check the operation of the device to ensure that the emitted laser beam is stable and safe.

ADDITIONAL WARNINGS

10. Child :safety

- Never allow children to use the laser pointer without adult supervision.
- Keep the indicator out of the reach of children to prevent accidental use.

11. Use in public areas:

- Laser pointers may be prohibited or restricted in public places (e.g. airports, concerts). Before use, ensure that local regulations allow the use of the device.

12. Avoid modifications:

- Do not attempt to modify or repair yourself the indicator . In case of problems, contact the manufacturer or its authorised service centre.

13. Action in the event of an emergency:

- If the unit exhibits abnormal operation, such as overheating, sparking, unusual odour or noises, immediately switch it off and disconnect it from the power supply and then contact the service centre.
- If you observe any unsafe product behaviour, contact the manufacturer urgently.

THE IMPORTANCE OF COMPLYING WITH THE WARNINGS

Following the above warnings minimises the risk of personal injury, equipment failure and property damage. Ignoring the recommendations can lead to serious health and material risks. Keep yourself and your loved ones safe by observing the precautions indicated.

PRODUCER

NTEC sp. z o.o.
44B Chorzowska Street
44-100 Gliwice
POLAND
info@qoltec.com
tel: +48 32 600 79 89